



Introduction

Thank you for choosing the MightyMic S Shotgun microphone. In order to get the maximum benefit of the microphone you need to use an App designed to support all of the audio features such as MoviePro for video recording. Please visit our website for the latest info on Apps and features.

Safety Rules

- To ensure proper use of this Microphone please carefully read through this user manual.
- Be wary of any sharp edges, uneven surfaces, metal parts, accessories and their packaging so as to prevent any possible injuries to you or damages to the microphone.
- Do not modify, repair or dismantle this microphone. Doing so may result in complete failure of the device, etc. All of which, are not covered under the warranty.
- Do not use any solvents or volatile liquids to clean the microphone.
- Do not use the Microphone in a hazardous location.
- The package contains small parts and poses a CHOCKING HAZARD, particularly in children

Usage

- In order to use the microphone simply plug it into the headphone jack on your device. The microphone is powered by your device so there are no batteries needed. The power needed by the microphone is very small so there is no appreciable drain on the device battery.
- The microphone is a shotgun design. The effect is to minimize sounds from the back and sides compared with the built-in microphone. This will allow you to increase the microphone sensitivity in front of the microphone without having as much of the unwanted background sounds. The microphone is designed to cover a wide range of volume situations and does not have any increased sensitivity over the existing microphone by design. This will avoid overload problems.
- In order to control the microphone sensitivity you need to use a compatible App such as MoviePro for video.
- The microphone has a headphone jack on the rear for playback. It can also be used for monitoring during recording with a compatible App such as MoviePro. Using this App will allow you to listen and set sensitivity levels before recording and also listen while recording.

Warranty

Product warranty is limited to defects in material and workmanship for one year to the original purchaser. Warranty does not cover collateral damage due to misuse, abuse, incorrect use and other inappropriate uses of this product. The limitation of this warranty is to repair or replace the defective parts. Consequential and incidental damages are not covered under this warranty. This warranty gives you specific legal rights, you may also have other rights which vary from state to state. See details at ampridge.com for updated information.

Service and support

If your device is not performing as it should please visit

Package Contents



1 Microphone

1 Foam Windscreen

1 Carrying Bag